

ERRATA to CHARGE LED II, the text should read as follows:

The green LED next to the gain switch indicates the status of the charging.

**Fully lit:** The batteries are nearly empty and are being charged.

**Gradually dimming:** The charge in the batteries is increasing as the LED dims

**Very dimly lit:** The main charging has finished and the iQube is drippling charging the batteries.

**OUT:** There is no charger connected to the iQube